

The Vector 4Seasons Tyre Range

The Line	Dept	Diameter	Section Width	Rim Size	Load Index	Speed Index	Spec	Fuel Efficiency Class	Wet Grip	Noise Grade	Noise (db)
VECTOR 4 SEASONS	All Season	235	50	17	96	V		С	В	В	70
VECTOR 4 SEASONS	All Season	195	55	16	87	Н		D	С	В	71
VECTOR 4 SEASONS	All Season	195	60	16	99	Н		D	С	В	72
VECTOR 4SEASONS	All Season	165	70	14	89	R		D	В	В	71
VECTOR 4SEASONS	All Season	175	65	14	90	T		D	В	В	71
VECTOR 4SEASONS	All Season	185	55	14	80	Н		D	D	В	71
VECTOR 4SEASONS	All Season	175	65	13	80	Т		D	С	В	71
VECTOR 4SEASONS	All Season	255	45	18	99	V		D	С	В	71
VECTOR 4SEASONS	All Season	225	50	17	98	V	XL	В	С	В	71
VECTOR 4SEASONS	All Season	215	60	16	95	V		С	С	В	70
VECTOR 4SEASONS	All Season	205	50	17	93	V	XL	С	С	В	70
VECTOR 4SEASONS	All Season	195	60	16	89	Н		С	С	В	70
VECTOR 4SEASONS	All Season	205	50	17	89	V		С	С	В	70
VECTOR 4SEASONS	All Season	205	55	16	94	V	XL	С	С	В	70
VECTOR 4SEASONS	All Season	215	60	17	96	V		С	С	В	72
VECTOR 4SEASONS	All Season	215	60	17	96	Н		С	D	В	72
VECTOR 4SEASONS	All Season	215	55	16	97	V	XL	D	D	В	70
VECTOR 4SEASONS	All Season	195	65	15	91	T		D	D	В	71
VECTOR 4SEASONS	All Season	195	60	15	88	Н		D	С	В	71
VECTOR 4SEASONS CARGO	All Season	195	60	16	99	Н		D	В	В	72
VECTOR 4SEASONS CARGO	All Season	225	55	17	109	Н		В	В	В	71
VECTOR 4SEASONS CARGO	All Season	195	65	16	104	T		D	В	В	72
VECTOR 4SEASONS CARGO	All Season	235	60	17	117	S		D	С	В	72
VECTOR 4SEASONS CARGO	All Season	195	75	16	110	R		С	В	В	71
VECTOR 4SEASONS CARGO	All Season	205	75	16	113	R		С	В	В	72
VECTOR 4SEASONS CARGO	All Season	195	75	16	107	S		С	В	В	71
VECTOR 4SEASONS CARGO	All Season	215	65	15	104	T		D	С	В	72
VECTOR 4SEASONS CARGO	All Season	225	75	16	121	R		С	С	В	73
VECTOR 4SEASONS CARGO	All Season	235	65	16	115	S		С	В	В	72
VECTOR 4SEASONS CARGO	All Season	215	65	16	109	T		С	В	В	72
VECTOR 4SEASONS CARGO	All Season	215	75	16	116	R		С	С	В	72
VECTOR 4SEASONS CARGO	All Season	195	70	15	104	S		D	В	В	72
VECTOR 4SEASONS CARGO	All Season	225	70	15	112	R		С	В	В	73
VECTOR 4SEASONS CARGO	All Season	185	80	14	102	R		D	С	В	72
VECTOR 4SEASONS CARGO	All Season	205	75	16	110	R		С	В	В	72
VECTOR 4SEASONS CARGO	All Season	215	65	15	104	T		D	С	В	72
VECTOR 4SEASONS CARGO	All Season	215	65	16	106	T		D	С	В	72
VECTOR 4SEASONS CARGO	All Season	215	65	16	109	T		С	В	В	72

VECTOR 4SEASONS CARGO	All Season	225	65	16	112	R		С	А	В	73
VECTOR 4SEASONS CARGO	All Season	195	80	14	106	S		С	В	В	72
VECTOR 4SEASONS CARGO	All Season	205	65	15	102	T		D	В	В	72
VECTOR 4SEASONS CARGO	All Season	205	65	16	107	T		D	С	В	72
VECTOR 4SEASONS CARGO	All Season	195	75	16	107	S		С	В	В	72
VECTOR 4SEASONS GEN-2	All Season	225	45	17	94	V	XL	В	В	В	72
VECTOR 4SEASONS GEN-2	All Season	225	45	19	96	W	XL	С	В	В	71
VECTOR 4SEASONS GEN-2	All Season	195	50	15	82	Н		D	С	В	71
VECTOR 4SEASONS GEN-2	All Season	215	55	17	94	V		С	В	В	70
VECTOR 4SEASONS GEN-2	All Season	205	55	16	94	V	XL	В	В	В	72
VECTOR 4SEASONS GEN-2	All Season	195	55	16	87	Н		В	В	В	72
VECTOR 4SEASONS GEN-2	All Season	165	65	15	81	Т		В	С	Α	68
VECTOR 4SEASONS GEN-2	All Season	185	60	15	84	Т		В	В	В	70
VECTOR 4SEASONS GEN-2	All Season	225	45	18	95	V	XL	С	С	В	70
VECTOR 4SEASONS GEN-2	All Season	215	60	17	96	Н		В	В	В	71
VECTOR 4SEASONS GEN-2	All Season	195	55	16	91	V	XL	С	С	В	71
VECTOR 4SEASONS GEN-2	All Season	165	60	15	81	Т	XL	D	В	В	70
VECTOR 4SEASONS GEN-2	All Season	185	65	15	88	Т		С	В	В	70
VECTOR 4SEASONS GEN-2	All Season	235	50	18	101	V	XL	С	С	В	72
VECTOR 4SEASONS GEN-2	All Season	235	55	17	103	V	XL	С	В	В	71
VECTOR 4SEASONS GEN-2	All Season	205	55	17	95	V	XL	В	В	В	70
VECTOR 4SEASONS GEN-2	All Season	175	65	15	84	Н		С	В	В	70
VECTOR 4SEASONS GEN-2	All Season	225	60	16	102	W	XL	С	В	В	72
VECTOR 4SEASONS GEN-2	All Season	185	65	15	88	V	7.2	С	В	В	71
VECTOR 4SEASONS GEN-2	All Season	235	55	17	103	Н	XL	С	С	В	71
VECTOR 4SEASONS GEN-2	All Season	225	55	17	97	V	Λ.Ε	В	В	В	71
VECTOR 4SEASONS GEN-2	All Season	195	60	15	88	V		С	С	В	71
VECTOR 4SEASONS GEN-2	All Season	195	65	15	95	Н	XL	В	С	В	70
VECTOR 4SEASONS GEN-2	All Season	205	55	16	94	н	XL	В	С	В	72
VECTOR 4SEASONS GEN-2	All Season	225	45	17	94	V	XL	С	В	В	71
VECTOR 4SEASONS GEN-2	All Season	195	55	20	95	Н	XL	В	В	В	71
VECTOR 4SEASONS GEN-2	All Season	215	55	17	94	V	//L	С	В	В	71
VECTOR 4SEASONS GEN-2	All Season	215	60	16	95	V		С	В	В	70
VECTOR 4SEASONS GEN-2	All Season	165	65	14	79	T		D	D	В	70
		225	45	17	91	V		D	В	В	70
VECTOR 4SEASONS GEN-2	All Season	195	40 55	16	87	V H		D	В	В	70
VECTOR 4SEASONS GEN-2	All Season			-		V					
VECTOR 4SEASONS GEN-2 VECTOR 4SEASONS GEN-2	All Season All Season	205 175	55 70	16 13	91	V T		D D	B B	B B	71 70
		205	60	13 16	82 92	Н		С	В		70 69
VECTOR 4SEASONS GEN-2	All Season			-		T				A	
VECTOR 4SEASONS GEN-2	All Season	155	65 60	14	75 75			D	В	В	70 70
VECTOR 4SEASONS GEN-2	All Season	165 165	60 70	14 13	75 79	H T		D	С	В	70 70
VECTOR 4SEASONS GEN-2	All Season			_				D	В	В	
VECTOR 4SEASONS GEN-2	All Season	165	70 70	14	81	T	VI	D	В	В	70 70
VECTOR 4SEASONS GEN-2	All Season	165	70	14 15	85	T	XL	С	В	В	70
VECTOR 4SEASONS GEN-2	All Season	175	65 70	15	84	T		С	В	В	70
VECTOR 4SEASONS GEN-2	All Season	175	70	14	84	T		D	В	В	70
VECTOR 4SEASONS GEN-2	All Season	175	80	14	88	T		D	В	В	70
VECTOR 4SEASONS GEN-2	All Season	185	60	15	88	H	XL	С	В	В	71
VECTOR 4SEASONS GEN-2	All Season	185	70	14	88	T 		С	В	В	71
VECTOR 4SEASONS GEN-2	All Season	155	70	13	75	Т		D	С	В	70

VECTOR 4SEASONS GEN-2	All Season	185	65	15	88	T		С	В	В	71
VECTOR 4SEASONS GEN-2	All Season	195	55	15	85	Н		С	В	В	71
VECTOR 4SEASONS GEN-2	All Season	215	45	16	90	V	XL	С	В	В	71
VECTOR 4SEASONS GEN-2	All Season	215	50	17	95	V	XL	С	В	В	70
VECTOR 4SEASONS GEN-2	All Season	195	65	15	91	Н		В	С	В	72
VECTOR 4SEASONS GEN-3	All Season	235	50	19	103	W	XL	В	В	В	72
VECTOR 4SEASONS GEN-3	All Season	215	50	19	93	Н		С	В	В	71
VECTOR 4SEASONS GEN-3	All Season	155	70	19	88	T	XL	С	В	В	70
VECTOR 4SEASONS GEN-3	All Season	225	45	18	95	W	XL	С	В	В	71
VECTOR 4SEASONS GEN-3	All Season	225	50	17	98	W	XL	D	В	В	71
VECTOR 4SEASONS GEN-3	All Season	215	45	20	95	T	XL	А	В	В	72
VECTOR 4SEASONS GEN-3	All Season	205	60	16	96	V	XL	С	В	В	70
VECTOR 4SEASONS GEN-3	All Season	215	50	19	93	Н		С	В	В	72
VECTOR 4SEASONS GEN-3	All Season	235	55	18	100	V		В	В	В	72
VECTOR 4SEASONS GEN-3	All Season	245	45	20	103	W	XL	С	В	В	72
VECTOR 4SEASONS GEN-3	All Season	255	45	20	105	W	XL	С	В	В	72
VECTOR 4SEASONS GEN-3	All Season	255	40	20	101	W	XL	С	В	В	73
VECTOR 4SEASONS GEN-3	All Season	255	40	19	100	Y	XL	С	В	В	73
VECTOR 4SEASONS GEN-3	All Season	225	45	17	94	W	XL	D	В	В	71
VECTOR 4SEASONS GEN-3	All Season	215	55	17	98	W	XL	В	В	В	70
VECTOR 4SEASONS GEN-3	All Season	245	40	19	98	Y	XL	С	В	В	72
VECTOR 4SEASONS GEN-3	All Season	255	35	19	96	Y	XL	С	В	В	72
VECTOR 4SEASONS GEN-3	All Season	205	55	19	97	V	XL	В	В	В	72
VECTOR 4SEASONS GEN-3	All Season	245	50	19	105	W	XL	В	В	В	72
VECTOR 4SEASONS GEN-3	All Season	235	60	18	103	Т		В	В	В	71
VECTOR 4SEASONS GEN-3	All Season	255	55	18	105	Т		В	В	В	71
VECTOR 4SEASONS GEN-3	All Season	255	55	18	105	Т		В	В	В	71
VECTOR 4SEASONS GEN-3	All Season	235	60	18	103	Т		В	В	В	71
VECTOR 4SEASONS GEN-3	All Season	195	60	18	96	Н	XL	Α	В	В	72
VECTOR 4SEASONS GEN-3	All Season	185	65	15	92	Т	XL	В	С	В	70
VECTOR 4SEASONS GEN-3	All Season	185	55	15	86	V	XL	С	В	В	70
VECTOR 4SEASONS GEN-3	All Season	215	65	16	102	Н	XL	Α	В	В	71
VECTOR 4SEASONS GEN-3	All Season	205	50	17	93	W	XL	С	В	В	71
VECTOR 4SEASONS GEN-3	All Season	215	50	17	95	W	XL	С	В	В	72
VECTOR 4SEASONS GEN-3	All Season	195	45	16	84	V	XL	D	В	В	70
VECTOR 4SEASONS GEN-3	All Season	195	60	15	92	V	XL	С	В	В	71
VECTOR 4SEASONS GEN-3	All Season	225	50	18	99	W	XL	С	В	В	72
VECTOR 4SEASONS GEN-3	All Season	245	40	18	97	W	XL	С	В	В	72
VECTOR 4SEASONS GEN-3	All Season	245	45	17	99	Y	XL	В	С	В	71
VECTOR 4SEASONS GEN-3	All Season	195	55	16	91	V	XL	С	В	В	70
VECTOR 4SEASONS GEN-3	All Season	215	40	18	89	W	XL	С	В	В	72
VECTOR 4SEASONS GEN-3	All Season	215	50	18	92	W	/_	С	В	В	71
VECTOR 4SEASONS GEN-3	All Season	215	60	16	99	V	XL	С	В	В	71
VECTOR 4SEASONS GEN-3	All Season	225	45	18	95	W	XL	С	В	В	71
VECTOR 4SEASONS GEN-3	All Season	245	45	18	100	Y	XL	В	В	В	72
VECTOR 4SEASONS GEN-3	All Season	245	60	15	95	V	XL	В	В	В	72
VECTOR 4SEASONS GEN-3	All Season	205	65	15	99	V	XL	В	В	В	71
VECTOR 4SEASONS GEN-3	All Season	215	55	16	99	V	XL	С	В	В	71
			55 40	18		Y		C	В	В	72
VECTOR 4SEASONS GEN-3	All Season	225			92		XL				
VECTOR 4SEASONS GEN-3	All Season	225	55	17	101	Y	XL	В	В	В	72

VECTOR 4SEASONS GEN-3	All Season	195	65	15	95	V	XL	С	В	В	71
VECTOR 4SEASONS GEN-3	All Season	225	55	17	101	V	XL	Α	В	В	72
VECTOR 4SEASONS GEN-3	All Season	205	55	16	94	V	XL	А	В	В	72
VECTOR 4SEASONS GEN-3	All Season	195	55	16	91	Н	XL	А	В	В	72
VECTOR 4SEASONS GEN-3	All Season	205	55	17	95	V	XL	В	В	В	71
VECTOR 4SEASONS GEN-3	All Season	205	60	16	92	Н		С	В	А	69
VECTOR 4SEASONS GEN-3	All Season	225	50	17	98	W	XL	С	В	В	70
VECTOR 4SEASONS GEN-3	All Season	185	60	15	88	V	XL	С	В	В	70
VECTOR 4SEASONS GEN-3	All Season	215	65	16	102	V	XL	С	В	В	72
VECTOR 4SEASONS GEN-3	All Season	235	40	18	95	W	XL	С	В	В	72
VECTOR 4SEASONS GEN-3	All Season	205	45	17	88	W	XL	D	В	В	70
VECTOR 4SEASONS GEN-3	All Season	225	55	16	99	W	XL	С	В	В	71
VECTOR 4SEASONS GEN-3	All Season	175	65	14	86	Н	XL	С	В	В	69
VECTOR 4SEASONS GEN-3	All Season	185	60	14	86	Н	XL	С	В	В	70
VECTOR 4SEASONS GEN-3	All Season	185	65	14	86	Н		С	В	В	70
VECTOR 4SEASONS GEN-3	All Season	185	65	15	92	Т	XL	С	В	В	70
VECTOR 4SEASONS GEN-3	All Season	185	65	15	92	V	XL	С	В	В	70
VECTOR 4SEASONS GEN-3	All Season	195	60	16	93	V	XL	С	В	В	70
VECTOR 4SEASONS GEN-3	All Season	205	55	16	91	٧		С	В	В	70
VECTOR 4SEASONS GEN-3	All Season	205	55	16	94	٧	XL	С	В	В	70
VECTOR 4SEASONS GEN-3	All Season	205	60	16	96	V	XL	С	В	В	70
VECTOR 4SEASONS GEN-3	All Season	215	45	17	91	W	XL	С	В	В	70
VECTOR 4SEASONS GEN-3	All Season	215	55	17	98	W	XL	В	В	В	70
VECTOR 4SEASONS GEN-3	All Season	215	60	17	100	Н	XL	А	В	В	72
VECTOR 4SEASONS GEN-3	All Season	215	60	17	100	V	XL	А	В	В	72
VECTOR 4SEASONS GEN-3	All Season	225	45	17	94	W	XL	С	В	В	70
VECTOR 4SEASONS GEN-3	All Season	225	55	17	101	W	XL	В	В	В	72
VECTOR 4SEASONS GEN-3	All Season	225	55	18	102	٧	XL	А	В	В	72
VECTOR 4SEASONS GEN-3	All Season	225	55	18	102	W	XL	В	В	В	71
VECTOR 4SEASONS GEN-3	All Season	235	45	17	97	Y	XL	С	В	В	71
VECTOR 4SEASONS GEN-3	All Season	235	55	17	99	Н		В	В	В	72
VECTOR 4SEASONS GEN-3	All Season	235	55	17	103	Υ	XL	В	В	В	72
VECTOR 4SEASONS GEN-3	All Season	235	60	17	102	Н		В	В	В	72
VECTOR 4SEASONS GEN-3	All Season	245	45	19	102	W	XL	С	В	В	72
VECTOR 4SEASONS GEN-3	All Season	255	45	19	100	W		С	В	В	72
VECTOR 4SEASONS GEN-3	All Season	235	45	18	98	Y	XL	С	В	В	71
VECTOR 4SEASONS GEN-3	All Season	175	65	15	88	Н	XL	С	В	В	71
VECTOR 4SEASONS GEN-3 SUV	All Season	255	50	20	109	W	XL	В	В	В	73
VECTOR 4SEASONS GEN-3 SUV	All Season	255	45	20	105	T	XL	С	В	В	72
VECTOR 4SEASONS GEN-3 SUV	All Season	235	55	18	104	V	XL	С	В	В	72
VECTOR 4SEASONS GEN-3 SUV	All Season	255	60	18	112	V	XL	В	В	В	73
VECTOR 4SEASONS GEN-3 SUV	All Season	225	50	19	100	V	XL	С	С	В	72
VECTOR 4SEASONS GEN-3 SUV	All Season	215	65	17	103	V	XL	С	В	В	72
VECTOR 4SEASONS GEN-3 SUV	All Season	255	45	19	104	W	XL	С	В	В	71
VECTOR 4SEASONS GEN-3 SUV	All Season	275	45	20	110	Y	XL	В	В	В	73
VECTOR 4SEASONS GEN-3 SUV	All Season	225	50	18	99	W	XL	С	В	В	72
VECTOR 4SEASONS GEN-3 SUV	All Season	235	55	18	104	V	XL	С	В	В	72
VECTOR 4SEASONS GEN-3 SUV	All Season	315	35	20	110	W	XL	С	В	В	74
VECTOR 4SEASONS GEN-3 SUV	All Season	235	55	19	105	W	XL	С	В	В	72
VECTOR 4SEASONS GEN-3 SUV	All Season	235	65	17	108	W	XL	С	В	В	72
· · · · · · · · · · · · · · · · · · ·											

VECTOR 4SEASONS GEN-3 SUV	All Season	215	65	16	102	V	XL	С	В	В	72
VECTOR 4SEASONS GEN-3 SUV	All Season	215	65	17	99	V		С	В	В	72
VECTOR 4SEASONS GEN-3 SUV	All Season	235	60	18	107	W	XL	С	В	В	72
VECTOR 4SEASONS GEN-3 SUV	All Season	225	60	17	103	V	XL	С	В	В	72
VECTOR 4SEASONS GEN-3 SUV	All Season	225	60	18	104	W	XL	С	В	В	72
VECTOR 4SEASONS GEN-3 SUV	All Season	215	60	17	100	V	XL	В	В	В	71
VECTOR 4SEASONS GEN-3 SUV	All Season	225	65	17	106	V	XL	С	В	В	72
VECTOR 4SEASONS GEN-3 SUV	All Season	235	55	17	103	Υ	XL	В	В	В	72
VECTOR 4SEASONS GEN-3 SUV	All Season	245	45	19	102	W	XL	С	В	В	72
VECTOR 4SEASONS GEN-3 SUV	All Season	255	45	19	100	W		С	В	В	72
VECTOR 4SEASONS GEN-3 SUV	All Season	255	55	18	109	Υ	XL	С	В	В	72
VECTOR 4SEASONS SUV GEN-2	All Season	235	55	18	100	V		В	С	В	72
VECTOR 4SEASONS SUV GEN-2	All Season	215	55	18	99	V	XL	С	В	В	72
VECTOR 4SEASONS SUV GEN-2	All Season	235	60	18	107	W	XL	С	В	В	71
VECTOR 4SEASONS SUV GEN-2	All Season	255	55	19	107	V		В	В	В	72
VECTOR 4SEASONS SUV GEN-2	All Season	255	60	18	108	V		В	В	В	73
VECTOR 4SEASONS SUV GEN-2	All Season	235	45	19	99	V	XL	С	В	В	72
VECTOR 4SEASONS SUV.4X4	All Season	215	70	16	100	T		D	С	В	71
VECTOR 4SEASONS SUV.4X4	All Season	235	55	17	103	Н	XL	D	С	В	70
VECTOR 4SEASONS SUV.4X4	All Season	235	55	17	99	V		D	С	Α	69